



PERFORMANCE MACHINE LIMITED WARRANTY INFORMATION

Performance Machine warrants to the original purchaser that the parts of this headlight bezel to be free of manufacturing defects in materials and workmanship for a period of one (1) year from the date of purchase. In the event warranty service is required, you must call Performance Machine immediately with a description of the problem.

If it is deemed necessary for Performance Machine to make an evaluation to determine whether the part is defective, a return authorization number will be given by Performance Machine. The parts must be packaged properly so as to not cause further damage and returned prepaid to Performance Machine with a copy of the original invoice of purchase and a detailed letter outlining the nature of the problem. If after the evaluation by Performance Machine the part was found to be defective it will be repaired or replaced at no cost to you. If we replace it, we may replace it with a reconditioned one of the same design.

Performance Machine shall not be held liable for any consequential or incidental damages resulting from the failure of a Performance Machine part.

Performance Machine shall have no obligation if a part becomes defective as a result of improper installation or abuse.

IMPORTANT NOTICE

Before installing this headlight bezel, read through these instructions completely; this will familiarize you with the way in which the parts fit together and the tools needed to complete the job.

The PM FLH headlight bezel involves alterations to your motorcycle and may void your factory warranty. PM STRONGLY recommends this installation be done by an experienced motorcycle mechanic.

DISCLAIMER

These Performance Machine parts are designed for high performance motorcycle applications and are intended for the very experienced rider only. The installation of these Performance Machine parts may adversely effect or void your factory warranty.

1. Turn off your motorcycle and place securely on a lift or the sidestand.
2. Using a phillips screwdriver remove the factory headlight bezel screw and pull the bezel outward. (Refer to your HD service manual for additional instructions)



3. Take note of the position of the top spring which has a special loop that engages in the headlight mount. Remove the factory rubber weather strip gasket and the 3 springs.






PERFORMANCE MACHINE FLH HEADLIGHT BEZEL INSTALLATION (CONTINUED)

4. Install the factory rubber weather strip and springs on the new PM headlight bezel as shown below. Note: the top spring must be at the 12 o'clock position opposite of the screw hole and the other two springs should be mounted approximately 120 degrees from each other.



5. Install the PM headlight bezel on the motorcycle by placing the ring over the headlight and hooking the top spring loop onto the headlight mount tab. Once the spring is hooked, push the PM bezel completely onto the headlight mount.
(Refer to your HD service manual for additional instructions)



6. With the PM headlight bezel full seated, install the supplied #8 screw using a phillips head screwdriver. Do not overtighten.



7. Hit the road!

CONTACT INFORMATION

Performance Machine
6892 Marlin Circle
La Palma, California
90623 - USA

Toll Free: 800-479-4037

Direct: 714-523-3000

Fax: 714-523-3007

Email: tech@performancemachine.com

Website: performancemachine.com